Operating Equipment in 2D1

Turn on Projector: Using the SHARP projector remote aim remote towards projector on the ceiling and press ON.

To **project the computer**, make sure the tan switcher is set to computer (A). Then press INPUT 1 on the projector remote until the computer is displayed. The computer input is on INPUT 1. (Turn the computer and the computer monitor on if necessary by pressing their power buttons and operate the computer and you normally would.)

To **project the document presenter**, make sure the tan switcher is set to doc presenter (B). Then press INPUT 1 on the projector remote until the document presenter displays. The document presenter input is on INPUT 1. (Turn on the document presenter by pressing its Power button.)

To **project the VCR or DVD** , press INPUT 2 until VCR/DVD displays. The VCR/DVD player is on input INPUT 2.

        To adjust VCR/DVD audio use the projector remote. Volume buttons are on the top right of the remote.

When Finished:

        Turn off the projector pressing the STANDBY button TWICE on the projector remote.
        Turn off the document presenter.
        Turn off the VCR
        You may leave the computer on.