

Operating Equipment in Enhanced Classroom – 2C3B

Use the Black Remote (labeled PROJECTOR) to operate the projector and to select the components you wish to project

To **Turn on the Projector**: press the RED button (top right corner of the projector remote)

To **Project the Computer**: press MY BUTTON 1 on Projector Remote.

To **Project the Document Presenter**, press MY BUTTON 2 on the Projector Remote.

Turn on the document presenter by pressing the power button on the document presenter. (Red=off/Blue=on).

To **project a DVD**, Use the CD/DVD drive in the computer

When Finished:

Turn off the projector by pressing the RED button (**TWO times**) on the projector remote.

Turn off the document presenter.

You may leave the computer and monitor on.

